8-CAMERA SWITCHER HARNESS

6-PinHarness · Connects to the POWER header on the Switcher Board

TOTAL VISION PRODUCTS

WIRING INSTRUCTIONS

View: looking into the wire end of the header as it plugs onto the ECU.
Match ridge-lock orientation.

Switcher board - POWER header highlighted





Magnified: POWER header, wire end view

Pins 1 and 2 are required for basic operation.
Pins 3–6 are optional inputs.

Pin	Color	Wire	Function
1		Red	Switched +12V power
2		Black	System ground
3		Blue	Back-up light circuit
4		Yellow	Dash / running light
5		White	Right turn signal
6		Purple	Left turn signal